

BALCONY RAILING REPLACEMENT

Let Southern Lumber Company show you what's involved in railing replacement.

LIST OF NEEDED STEPS:

1. Measure railing runs (Length).
2. Determine railing height (advisable to check local building codes).
3. Determine top rail width (advisable to check local building codes).
4. Select railing style to be used.
5. Select style of Newel Post.
6. Select Baluster style and size (advisable to check local building codes).
7. Place order.
8. Start by carefully removing existing railing.
9. Mark layout lines on floor surface where all Newel Post will be located.
10. Assemble rail sections.
11. Install Newel Post.
12. Install pre-assembled railing sections.
13. Install bottom rail support blocks (If necessary).
14. Clean up site.

Checklist of Needed Supplies:

- Baluster, Railing, and Newel Post (Bottom rail support blocks if applicable).
- Primer
- Paint
- Stain & Finish (If applicable)
- Sandpaper
- Adhesive
- Filler / Putty

Recommended Tools:

- ✓ Hammer
- ✓ Screwdriver
- ✓ Drill
- ✓ Level
- ✓ Wrenches
- ✓ Tape Measure
- ✓ Chisel
- ✓ Sander
- ✓ Safety Goggles

PROJECT DIFFICULTY:

NOVICE

HOME HOBBYIST

INTERMEDIATE

ADVANCED