

MOULDING REPLACEMENT

Let Southern Lumber show you the fast and easy way to spruce up a room.

LIST OF NEEDED STEPS:

1. Determine rooms to be worked on.
2. Measure affected walls.
3. Carefully look for areas of concern (A close wall, A window, or Door opening).
4. Select style and type to best fit area, and associated mouldings.
5. Make a cut list.
6. Place order.
7. Will Call or have delivered.
8. Separate by length.
9. Work from cut list.
10. Double check each measurement prior to cutting.
11. Prime mouldings if painting, or Stain and Finish prior to installation.
12. Fill holes left from mounting.
13. Touch up.

CHECKLIST OF NEEDED SUPPLIES:

- | | |
|--|---|
| <input type="checkbox"/> Mouldings | <input type="checkbox"/> Stain & Finish |
| <input type="checkbox"/> Chamfer Block (If Crown Moulding is to be installed). | <input type="checkbox"/> Paint Brush |
| <input type="checkbox"/> Nails | <input type="checkbox"/> Sandpaper |
| <input type="checkbox"/> Primer & Paint | <input type="checkbox"/> Tack Cloth |
| | <input type="checkbox"/> Drop Cloth |

RECOMMENDED TOOLS:

- | | |
|--|--|
| <input checked="" type="checkbox"/> Hammer | <input checked="" type="checkbox"/> Level |
| <input checked="" type="checkbox"/> Drill | <input checked="" type="checkbox"/> Putty Knife |
| <input checked="" type="checkbox"/> Tape Measure | <input checked="" type="checkbox"/> Nail Set |
| <input checked="" type="checkbox"/> Miter Box | <input checked="" type="checkbox"/> Can Opener |
| (Electric Chop Saw) | <input checked="" type="checkbox"/> Safety Goggles |

PROJECT DIFFICULTY:

NOVICE

HOME HOBBYIST

INTERMEDIATE

ADVANCED